## SEL-351A-1

## **Phasor Measurement Unit**

Standard with Ethernet, USB, IEEE C37.118 Synchrophasor Measurement, DNP3 Outstation, Modbus® TCP/RTU, LCD and Enabled  $LED^{(1)}$ , 8 Outputs<sup>(2)</sup>, 6 Inputs, Conventional Terminal Blocks, AcSELERATOR QuickSet® SEL-5030 Software<sup>(3)</sup>

Part Number:		0	3	5	1	A	1		2	X						
Chassis and Mounting																
2U Horizontal Rack Mount								R								
2U Horizontal Panel Mount								Р								
2U Horizontal Projection Panel Mount*								Т								
Power Supply																
24/48 Vdc											2					
48/125 Vdc or 120 Vac											3					
125/250 Vdc or 120/230 Vac											4					
Communications Inter	face															
(1)100Base-FX MM LC, EIA-4	85*											D				
(2)10/100Base-T, EIA-485*												Ε				
(2)100Base-FX MM LC, EIA-485*												F				
Secondary Input Curre	nt															
1 Amp Phase, 1 Amp Neutral													1			
5 Amp Phase, 5 Amp Neutral													5			
5 Amp Phase, 1 Amp Neutral													6			
Control Input Voltage																
24 Vdc														1		
48 Vdc														2		
110 Vdc														3		
125 Vdc														4		
220 Vdc														5		
250 Vdc														6		
Conformal Coat																
None															Χ	
Conformal Coated Circuit Boards*															2	
Communications Proto	cols															
Standard Protocols																1
Standard plus IEC 61850*																2
Accessories																
Literature																
	Printed Instruction Manual <sup>(5)</sup>	P	<b>4</b> 3	5 1	Α	- 0	2									

<sup>\*</sup> Additional Cost

 $<sup>^{(1)}</sup>$  The SEL-351A-1 Phasor Measurement Unit has a single front panel LED which illuminates when the unit is functional.

<sup>(2)</sup> OUT101 and OUT102 are configured as Hybrid High-Current Interrupting output contacts.

<sup>(3)</sup> Download ACSELERATOR Quickset SEL-5030 software for free at <a href="http://www.selinc.com/SEL-5030">http://www.selinc.com/SEL-5030</a>. ACSELERATOR Quickset on CD

(503001WX4) is available upon request. (4) The SEL-351A-1 Phasor Measurement Unit comes standard with a CD manual. One complimentary printed instruction manual is available upon request with each product purchased.

Note: Accepts single-phase voltage up to 300V line-neutral or three-phase voltages up to 300V line-neutral, wye or delta connection configurable via global setting.

Making Electric Power Safer, More Reliable, and More Economical®

SEL SCHWEITZER ENGINEERING LABORATORIES, INC.

2350 NE Hopkins Court - Pullman, WA 99163 USA Phone: +1.509.332.1890 - Fax: +1.509.332.7990