

set_1.txt

*** Note - disabled and unused settings not shown. ***

RELAYTYPE=0587
FID=SEL-587-1-RXXX-VXX-Z001001-DXXXXXXXXX
PARTNO=0587103X5P1

RID = 87T1
TID = COMMISSIONING EXAMPLE
MVA = OFF
VWDG1 = 138.00
VWDG2 = 69.00
TRCON = DABY
CTCON = YY
RZS = Y
CTR1 = 180
CTR2 = 240
TAP1 = 1.00
TAP2 = 4.32
O87P = 0.5
SLP1 = 25
SLP2 = 55
IRS1 = 3.0
U87P = 10.0
PCT2 = 15
PCT4 = 15
PCT5 = 35
TH5 = 3.2
TH5D = 0.000
DCRB = Y
HRSTR = N
IHBL = N
50P1H = 7.5
50P1HC = N
51P1P = 0.5
51P1C = U1
51P1TD = 3.00
51P1RS = N
51P1TC = N
LTRP = N
TDURD = 9.000
NFREQ = 60
PHROT = ABC
MTU1 = 51P1T+50P1H
MTU2 = RB2
MTU3 = 87R+87U
MER = 87R+87U+50P1H+51P1T
OUT1 = TRP1
OUT2 = TRP1
OUT3 = TRP3*IN1