Human-Machine Interface (HMI) for SEL Real-Time Automation Controllers (RTACs)



Device-level HMI for system visualization and control

- Deliver efficient HMI solutions by building effective operator interface screens through easy-to-use tools without the need for mapping data tags.
- Identify changing system conditions and make informed decisions based on real-time analysis without the need of any special software to view the HMI.
- Leverage powerful and reliable RTAC hardware with a cost-effective HMI option for local/remote monitoring, control, integrated alarms, and annunciation.
- Monitor your system and analyze performance anywhere, anytime with a secure, web-based, thin client user interface.



RTAC HMI

The RTAC HMI offers an easy way to visualize data and create custom diagrams to monitor and control your system. The HMI provides authenticated access for multiple users from multiple locations and is viewable from a web browser. It renders natively on browsers compatible with HTML5 web standard—no plugins required.

Browser-Based Local and Remote Access

Access the RTAC HMI locally or remotely via a web browser interface from the web server on the RTAC unit. On-demand visualization and control makes monitoring and controlling your system a more efficient task. Role-based accounts provide appropriate security access. Since it is a thin client, no installation and no upkeep for a specific application are required.


All-in-One Box Solution

Combine your need for automation processing and HMI visualization into one box with the high-performance SEL-3555, SEL-3560, and SEL-3350 RTACs.

The video output port of these RTAC models directly connects to a monitor, eliminating the need to have an additional substation computer dedicated to running the HMI. This reduces capital expenditures and operational cost while increasing reliability by reducing points of failure in your substation.


Note, this all-in-one functionality is specific to the SEL-3555, SEL-3560, and SEL-3350 RTACs. Other members of the SEL RTAC family require an additional computer for video output.





Monitor Substation Performance, and Execute Control Decisions

See the system status in a way that is customized to the individual user's preference. Detect system conditions as they change, and identify potential failure points. Integrated alarms will alert operators when there is a problem. Complete customization of the alarm response ensures that alarms provide the right information at the right time. The RTAC HMI provides the necessary information and the ability to execute control decisions from the HMI interface.



Visualize analog data.

Tooltip trend with graphical trend data (above) and tabular trend data (below).


Visualize the device status.

Feeder 1 Detail		MOTOR CONTROL
	Indicators Q. Controls - Feeder 1 Breaker L Status " Enabled Tap Descatornoos Place Overcurrent Come C	START STOP TRIP MOTOR RUNNING
SEL-751A SEL-751A SEL-751A FEEDER RELAY MICE CONTINUES FEEDER RELAY	Cochristed overunet Cochristed overune Cochristed	DATA Metering Value Magnitude Metering Value Magnitude CURRENT POWER IA DOA 5 DOVA
	Meter Values Maasumment Value POWV 0.000	B 0.0 A P 0.0 W IC 0.0 A Q 0.0 VAR KG 0.0 A PF 0.0 N 0.0 A PF 0.0
Artiketuneus Medioverset Medioverset Medioverset Medioverset Medioverset Medioverset Medioverset	وthere که در میلی و در مع	MOTOR LOAD 0.0 PU VOLTAGE
ALE LECT VERCOMENT ONLANCES FECONICY SECACE FALLINE TELEP Market Sets	Phase Value IA(A) Cato BB(A) 0.00	VA 0.0 V ROTOR TCU 0.0 % VB 0.0 V STATOR TCU 0.0 % VC 0.0 V STATOR TCU 0.0 %
SEL - 751A - Feeder Protection Relay	K(A) 800	FREQUENCY 0.0 Hz IMBALANCE Voltage Imbalance 0.0 % Current Imbalance 0.0 %

Promote Situational Awareness

Use the RTAC HMI to monitor critical industrial processes. Detect system misoperation and early warning signs for necessary system maintenance to improve system reliability.





Advanced Warning

Enable operators to be proactive versus reactive by using the available trending feature that provides quick and easy visualization of the data values over a definite period of time, configurable both at design time and at run time.

0.00	0.00	0.00	0.00	0.00	IB (A)
0.00	0.00	0.00	0.00	0.00	IC (A)
0.00					P(MW)
0.00					Q (MVar)
0.00@0					Phase & Freq.
SIMULATOR	L_TAGS.Fe	eder 🗆 🗧	× SIMUL	ATOR_TA	GS.Gener □ ×

Get Instant Feedback

Promptly see the system response after taking a control action by analyzing data in real time via chart trending. Comparing system data over time against operating limits helps operators identify system dynamics and make more-informed control decisions.

ACSELERATOR Diagram Builder[™] SEL-5035 Software


Design Your HMI System Using the Included Diagram Builder Software

Diagram Builder is a Microsoft Windows PC-based software application. It is a free configuration tool that is designed to simplify the process of HMI diagram creation. Drag and drop controls onto your diagram design palette, easily align and group diagram controls, and speed up tag assignment with the find-and-replace functionality.

Diagram Builder offers a predefined library with predesigned controls for power systems, including parameters tailored for the visualization and operation of power systems.

Logical User Interface


When designing diagrams for HMI systems, the configuration software interface needs to support an efficient and intuitive workflow. Diagram Builder tools are arranged for the convenience of the designer, with the most commonly used capabilities readily available from the main interface.



Predesigned controls

Rich Object Template

Quickly deploy a new display using the library of controls available in Diagram Builder. Just drag a control onto the diagram design palette and adjust the properties in order to achieve the desired customized visualization. Predefined templates are available upon request from your SEL customer service representative.



Automatic Tag Mapping

Save time and reduce errors with automatic tag mapping between the RTAC tag database and Diagram Builder. You can choose to import the entire tag list or just the needed items, depending on your workflow.

1	🛃 Import RTAC Tags						×			
	IOC	ISC	LEDC	MDBC	MRBC	MV	SBRC	SPS	SRBC	STR
	Conn	ection	APC	BAC	BCR	BSC	CMV	DNPC	INC	INS
	General Advanced Database Connection Properties © Direct To RTAC © Direct To AcSELerator RTAC Database IP Address 172 · 29 · 131 · 1 User Name									
	-	Password			Test Cor	nection				
	Load Tags									
	Select All Available Tags Of Every Type Done Cancel						el			

Specifications

Client Hardware Requirements for HMI1 Visualization	Rendered in HTML5
Web Browsers	Google Chrome Version 40 or higher Opera Version 27 or higher
Operating Systems	Microsoft Windows SP1 Ubuntu Linux Version 14.04
Minimum Client PC Processor	Intel Core Duo 2 GHz
Minimum RAM	2 GB

Minimum System Requirements for Diagram Builder Software			
Operating Systems	Windows 7 ² Microsoft Windows Server 2008 ²		
Processor	2.0 GHz dual core processor, GPU-enabled video driver		
RAM	4 GB		
Disk Space	100 MB		

¹The integrated video port of the SEL-3555, SEL-3560, and SEL-3350 RTACs uses an embedded web browser native to the RTAC to render the HMI graphics using HTML5. For all other web client connections, the RTAC will determine the type and version of web browser you are using and will automatically render the HMI graphics in HTML5.

²Requires user accounts with administrator permissions or higher.



Making Electric Power Safer, More Reliable, and More Economical +1.509.332.1890 | info@selinc.com | selinc.com

