# SEL-700BT

## Motor Bus Transfer Relay




# Comprehensive bus transfer protection for critical process environments

- Transfers critical loads from a primary source to an auxiliary feeder during faults on the primary feeder line.
- Allows automatic and manual motor bus transfers to keep processes running without requiring a cold start.
- Provides primary and backup motor bus protection with current, voltage, frequency, distance, loss-of-potential, and out-of-step elements.
- Support installations with low-energy analog (LEA) voltage sensors, Rogowski coils, and low-power current transformers (LPCTs).
- Improves network recovery via alternate paths in a network with the Rapid Spanning Tree Protocol (RSTP).



# **Functional Overview**



<sup>\*</sup>Optional feature

ANSI Functions				
25 (X,Y)	Synchronism Check			
27	Undervoltage			
271	Inverse-Time Undervoltage			
27S	Synchronism Undervoltage			
49R	Thermal Overload			
50N	Neutral Overcurrent			
50 (P,G,Q)	Overcurrent (Phase, Ground, Negative Sequence)			
51N	Neutral Time Overcurrent			
51 (P,G,Q)	Time Overcurrent (Phase, Ground, Negative Sequence)			
591	Inverse-Time Overvoltage			
59\$	Synchronism Overvoltage			
59 (P,G,Q)	Overvoltage (Phase, Ground, Negative Sequence)			
60LOP	Loss of Potential			
67 (P,G,Q)	Directional Overcurrent (Phase, Ground, Negative Sequence)			
77	Field Device*			
78VS	Vector Shift			
81 (O,U,R)	Over-/Underfrequency, Rate-of-Change of Frequency			

*Optional t	feature
-------------	---------

Additional Functions				
85 RIO	SEL MIRRORED BITS® Communications			
BF	Breaker Failure			
BRM	Breaker Wear Monitor			
DFR	Event Reports			
НМІ	Operator Interface			
LDP	Load Data Profiling			
LEA	LEA Voltage Sensor Inputs and Rogowski Coil/LPCT Inputs			
LGC	SELogic® Control Equations			
MET	High-Accuracy Metering			
SER	Sequential Events Recorder			
WEB	Web Server			

### **Key Features**

#### Motor Bus Transfer Protection

Because industrial facilities with critical processes require a reliable supply of electric power, they typically have two incoming sources. To ensure process continuity during a fault on the primary feeder, the SEL-700BT Motor Bus Transfer Relay quickly and safely transfers loads to an auxiliary feeder via one of four transfer methods: fast, in-phase, residual, or fixed-time. This instantaneous transfer of load keeps processes running without requiring a cold start, helps avoid costly shutdowns, provides personnel safety, and helps avoid environmental damage. Manual load transfer is also possible locally or remotely via communications.

#### **Comprehensive System Protection**

Protect equipment using phase, negative-sequence, residual-ground, and neutral-ground overcurrent elements with directional control. You can also apply phase, negative-sequence, residual-ground, and neutral-ground time-overcurrent elements. The SEL-700BT includes many advanced protection features that ensure secure and reliable operation, such as synchronism check and rate-of-change-of-frequency (ROCOF) controls.

#### **Easy Communications**

Choose from single or dual copper or fiber-optic Ethernet ports, serial communications, and several protocols, including MIRRORED BITS communications, RSTP, IEC 61850 Edition 2, EtherNet/IP, the firmware-based IEEE 1588 Precision Time Protocol (PTP), IEC 60870-5-103, and the Parallel Redundancy Protocol (PRP). Multiple Modbus TCP or Modbus serial sessions are available for custom configuration of your application. You can also use DNP3 serial or DNP3 LAN/WAN protocols. In addition, the IEC 61850 test mode enables in-service testing, which reduces commissioning time.

#### **LEA Sensor Inputs**

The SEL-700BT can be ordered with LEA inputs to support medium- and low-voltage applications that use low-energy voltage sensors and Rogowski coils or other low-power current sensors. Order your device with the combination of LEA current and voltage inputs that suits your application.

#### **Breaker Wear Monitoring**

Record accumulated breaker contact wear with the breaker monitor function, which uses the breaker manufacturer's specifications for defining operation limits. The internal monitor tracks the total number of close/open operations and integrates the interrupted current per phase. You can set an alarm to alert operators when measured and accumulated quantities approach maintenance thresholds. This information facilitates proactive breaker maintenance and replacement.


#### Reliable, Rugged Hardware

The SEL-700BT has an operating temperature range of -40° to +85°C (-40° to +185°F). It withstands vibration, electrical surges, fast transients, and extreme temperatures, meeting stringent industry standards. A conformal-coating option for the printed circuit boards provides an additional barrier against airborne contaminants, such as hydrogen sulfide, chlorine, salt, and moisture. In addition, the SEL-700BT is ATEX-certified and Underwriters Laboratories (UL) Class I, Division 2-certified for use in hazardous and potentially explosive environments.


### **Product Overview**



### Conventional CT and PT Input Option



### **LEA Current and Voltage Inputs Option**



<sup>\*</sup>Compliant with IEC 61869-6, -13 standards.

### **Touchscreen Display Features and Functions**

Bay Screen 1

5

The SEL-700BT relay comes standard with a 5-inch,  $800 \times 480$  color touchscreen display, which provides a one-line diagram mimic display for bay control and monitoring. You can view metered quantities, phasor diagrams, relay settings, event summaries, target statuses, and SER data.

#### Bay Screens and Bay Control

Select from predefined bay screens for various configurations, including main-main and maintie-main. You can also configure as many as five custom bay screens using the ACSELERATOR® Bay Screen Builder SEL-5036 Software and ACSELERATOR QuickSet® SEL-5030 Software.

With the bay screen, you can control multiple breakers and disconnects, initiate source transfers, and control the bus transfer scheme.

#### X-S 0 deg Y-S 0 deg BKX Motor Bus (мот (мот XFER to Terminal Y XFER: **READY** ★ LR | ACC Bay Screen 1 06/12/2019 12:02:14 Terminal X 5 X-S 0 deg ВКХ 0 deg Y-S Motor Bus Terminal Y BKY XFER to Terminal Y XFER: READY


Terminal X

06/12/2019 08:45:37

Terminal Y

#### **Breaker Control**

To control a breaker, simply tap the bay screens application on the home screen and then the breaker you want to control. When asked to confirm the action, choose Yes to complete the action.




#### Meter Fundamentals

View the real, reactive, and apparent power of each phase in your system, and monitor the power factor information to determine if the phase current leads or lags the phase voltage.

Fundamental Metering			03/27/2018 10:43:10	
5		А	В	С
	PX (kW)	7502	7549	7519
	QX(kVAR)	4089	4069	4081
^	SX (kVA)	8542	8575	8558
~	PFX	0.88 LAG	0.88 LAG	0.88 LAG
				X LR 2AC

#### **Meter Phasors**

View a graphical and textual representation of the real-time voltages and currents in a power system during balanced and unbalanced conditions. By analyzing the phasors, you can determine power system conditions.




#### Meter Energy

Display the real, reactive, and apparent energy metering quantities imported and exported by your system. You can reset the energy values via the display and record the time and date of reset. Whether your system is a net energy producer or consumer, metered quantities accurately account for the power system energy flow.



#### Full Onscreen Keyboard

Quickly and easily enter passwords, search for Relay Word bits, and enter or edit settings via the full onscreen keyboard.




### **Applications**

#### Motor Bus Transfer Solution

The SEL-700BT has built-in logic for motor bus transfer, which allows for the instantaneous transfer of load to an auxiliary feeder from the primary feeder during faults to the primary feeder. Manual load transfer is also possible locally or remotely via communications. The four automatic bus transfer methods available include:

- Fast, in which the transfer occurs shortly after the first breaker opens and before the phase of the residual voltage deviates from the system.
- In-phase, which occurs when the phase of the system voltage and the residual voltage align.
- Residual, in which the relay waits for the residual voltage to fall below a certain threshold before transferring the bus.
- Fixed-time, which is configurable via SELogic control equations.




#### Main-Main Configuration

A single SEL-700BT can protect and control a critical main-main load bus by selecting from two sources automatically.

#### Main-Tie-Main Configuration

Two SEL-700BT relays (one on each side of the intertie) are used to transfer the load bus between sources in a main-tie-main configuration. This allows the system to retain load diversity during normal operation and enables advanced transfer functions.



#### **Complete Overcurrent Protection**

Apply instantaneous and directional instantaneous overcurrent and time-overcurrent protection with as many as two sets of three-phase CTs and one neutral CT input. Phase overcurrent protection is provided for both three-phase inputs.

#### **RTD-Based Thermal Protection**


Acquire thermal data for alarm, monitoring, and trip functions in the SEL-700BT with a 10 RTD input card or an external 12 RTD SEL-2600 RTD Module.

#### **Synchronism Check**

The built-in synchronism-check function provides supervision on both the X side and the Y side for the acceptable voltage window and maximum percentage difference, maximum and minimum allowable slip frequency, target closing angle, and breaker closing delay. The tie synchronism-check function provides the closing window for the bus-tie breaker when connecting to a utility system.




### Easy to Set and Use



# Use QuickSet Software to Set, Monitor, and Control the SEL-700BT


With QuickSet, you can:

- Communicate with the SEL-700BT through any ASCII terminal, or use the QuickSet graphical user interface.
- Develop settings offline with a menu-driven interface and help screens. You can speed up installation by copying existing settings files and modifying application-specific items.
- Simplify the settings procedure with the rules-based architecture that automatically checks interrelated settings. Out-of-range or conflicting settings are highlighted for correction.



#### **Integrated Web Server**

Access basic SEL-700BT information on a standard Ethernet network with the built-in web server. View the relay status, SER data, metering information, and settings with easy access within a local network. For increased security, web server access requires a relay password and the information is limited to a read-only view. You can also upgrade the relay firmware through the web server.



# Use SEL-5601-2 SYNCHROWAVE® Event Software to Retrieve and Display Event Reports Recorded by the SEL-700BT

With SYNCHROWAVE Event, you can:

- Display event report oscillograms. You can view each report as a plot of magnitude versus time and select analog and digital points to build a custom display.
- Display phase and symmetrical component phasors. Displaying the phasor view of electrical data helps you better understand asymmetrical, three-phase faults. You can build a custom plot using per-phase and symmetrical component sequence currents and voltages.
- Retrieve event reports using serial or Ethernet communications links.



### **Retrofit Replacement Kits**

Easily replace existing motor bus transfer protection with the SEL-700BT and the applicable mounting kit. These kits provide everything needed to replace many existing relays with the SEL-700BT. No cutting or drilling is required when you use the optional mounting kits. Replacement of existing protection is quick and easy.

# **SEL-700BT Specifications**

General				
Display	5-inch color touchscreen display, 800 × 480 pixels	Optional Communications	Serial communications card (EIA-232/-485)	
AC Current Inputs	5 A or 1 A phase and 5 A or 1 A neutral	and I/O Cards	3 digital inputs (DI), 4 digital outputs (DO), 14–20 mA analog output (AO)	
Rogowski Coil-Based AC Current Inputs (RJ45)	30 Vrms continuous, ±185 V <sub>peak'</sub> 200 Vac for 10 seconds		4 DI, 4 DO	
			8 DO	
LPCT Inputs (RJ45)	4 Vrms continuous, ±11.3 V <sub>peak</sub> , 200 Vac for 10 seconds		8 DI 14 DI	
AC Voltage Inputs	300 Vac continuous, 600 Vac for		4 DI, 3 DO (2 Form C, 1 Form B)	
	10 seconds		4 analog inputs (AI)/4 AO	
LEA Voltage Sensor Inputs (RJ45)	8 Vrms continuous, ±12 V <sub>peak</sub> , 200 Vac for 10 seconds		10 RTD inputs  LEA voltage sensor inputs and  Rogowski coil/LPCT inputs	
Output Contacts	The relay supports Form A, B, and C outputs.	Language Support	English and Spanish	
Optoisolated Control Inputs	DC/AC control signals: 250, 220, 125, 110, 48, or 24 V	Power Supply	110-250 Vdc or 110-240 Vac Input voltage range: 85-275 Vdc or 85-264 Vac	
	As many as 26 inputs are allowed in ambient temperatures of 85°C (185°F) or less.		24–48 Vdc Input voltage range: 19.2–60 Vdc	
Frequency and	System frequency: 50, 60 Hz	Operating	-40° to +85°C (-40° to +185°F)	
Phase Rotation	Phase rotation: ABC, ACB	Temperature	Note: Front-panel display contrast is impaired for temperatures below -20°C (-4°F) and above +70°C (+158°F).  To view certifications for the SEL-700BT, please visit selinc.com/company/certifications.	
	Frequency tracking: 15-70 Hz (requires ac voltage inputs)			
Communications Protocols	SEL (Fast Meter, Fast Operate, and Fast SER), Modbus TCP/IP, Modbus RTU, DNP3, FTP, IRIG-B, Telnet, Simple Network Time Protocol (SNTP), EtherNet/IP, firmware-based IEEE 1588 PTP, IEC 61850 Edition 2, IEC 60870-5-103, PRP, RSTP, MIRRORED BITS communications, and IEEE C37.118-2005 (synchrophasors).	Certifications		

### **SEL** SCHWEITZER ENGINEERING LABORATORIES



